



Condensing Unit Protection Cover (Wall & Floor Mounts)

English

1 Mount back plate to the wall using screws provided - the back plate has a quick release bar to allow easy fitting around the condensing unit - the back plate also has a spirit level to assist with accurate alignment. (Fig 1)

2 Fix the side panels by locating the taps into the slots on the back plate - straighten panels inwards to allow the panels to drop down into place and locate. (Fig 2)

3 Fix the front panel with stainless steel safety screws provided.

4 Fix the top panel by locating the tabs into the slots on the back plate - slide the panel right to left and lower into place - fix with stainless steel safety screws provided.

5 Caps are provided to conceal screws. (Fig 3)

6 Panels are manufactured with pre-knock outs for refrigeration pipes. (Fig 4)

French

1 Mount back plate to the wall using screws provided - the back plate has a quick release bar to allow easy fitting around the condensing unit - the back plate also has a spirit level to assist with accurate alignment.

2 Fix the side panels by locating the taps into the slots on the back plate - straighten panels inwards to allow the panels to locate (show blown up image for tabs and slots).

3 Fix the front panel with stainless steel safety screws provided.

4 Fix the top panel by locating the tabs into the

slots on the back plate - slide the panel left to right and lower into place - fix with stainless steel safety screws provided.

5 Caps are provided to conceal screws

German

1 Mount back plate to the wall using screws provided - the back plate has a quick release bar to allow easy fitting around the condensing unit - the back plate also has a spirit level to assist with accurate alignment.

2 Fix the side panels by locating the taps into the slots on the back plate - straighten panels inwards to allow the panels to locate (show blown up image for tabs and slots).

3 Fix the front panel with stainless steel safety screws provided.

4 Fix the top panel by locating the tabs into the slots on the back plate - slide the panel left to right and lower into place - fix with stainless steel safety screws provided.

5 Caps are provided to conceal screws

Italian

1 Mount back plate to the wall using screws provided - the back plate has a quick release bar to allow easy fitting around the condensing unit - the back plate also has a spirit level to assist with accurate alignment.

2 Fix the side panels by locating the taps into the slots on the back plate - straighten panels inwards to allow the panels to locate (show blown up image for tabs and slots).

1 Fix the front panel with stainless steel safety screws provided.

2 Fix the top panel by locating the tabs into the slots on the back plate - slide the panel left to right and lower into place - fix with stainless steel safety screws provided.

3 Caps are provided to conceal screws

Spanish

1 Mount back plate to the wall using screws provided - the back plate has a quick release bar to allow easy fitting around the condensing unit - the back plate also has a spirit level to assist with accurate alignment.

2 Fix the side panels by locating the taps into the slots on the back plate - straighten panels inwards to allow the panels to locate (show blown up image for tabs and slots).

3 Fix the front panel with stainless steel safety screws provided.

4 Fix the top panel by locating the tabs into the slots on the back plate - slide the panel left to right and lower into place - fix with stainless steel safety screws provided.

5 Caps are provided to conceal screws

1 Mount back plate to the wall using screws provided - the back plate has a quick release bar to allow easy fitting around the condensing unit - the back plate also has a spirit level to assist with accurate alignment.

2 Fix the side panels by locating the taps into the slots on the back plate - straighten panels inwards to allow the panels to locate (show blown up image

for tabs and slots).

3 Fix the front panel with stainless steel safety screws provided.

4 Fix the top panel by locating the tabs into the slots on the back plate - slide the panel left to right and lower into place - fix with stainless steel safety screws provided.

5 Caps are provided to conceal screws

Size	Partcode	EXT INT	H	W	D
SMALL	9794-600-06	EXT	750	1150	490
		INT	720	1120	465
MEDIUM	9794-620-06	EXT	1150	1150	650
		INT	1120	1120	625
LARGE	9794-640-06	EXT	1450	1150	650
		INT	1420	1120	625
X LARGE	9794-660-06	EXT	1800	1150	650
		INT	1700	1120	625

CONTACT OUR SALES OFFICE FOR QUOTATION/DELIVERY

Units 7 - 9 - Trident Business Park
 Amy Johnson Way, Blackpool, FY4 2RP,
 United Kingdom
 Mobile: + 44 (0)7921 472 023
 Tel: + 44 (0)870 950 6378
 Fax: + 44 (0)870 950 6379
 Email: sales@sauermann-uk.com
www.sauermannpumps.co.uk

